




Situo 1 RTS II Situo 5 RTS II



EN INSTRUCTIONS
FR NOTICE
ES MANUAL DE INSTRUCCIONES

somfy.

Ref.5150179B



EN The Situo 1 RTS II remote control allows a group of one or more applications to be controlled. The Situo 5 RTS II remote control allows up to 5 groups of one or more applications to be controlled.

1. Safety and liability

1.1. Liability

These instructions must be kept by the user. Failure to follow these instructions or use of the product outside its field of application is forbidden and will invalidate the warranty and discharge Somfy of all liability.

This Somfy product must be installed by a professional drive and home automation installer. Moreover, the installer must comply with the standards and legislation currently in force in the country in which the product is being installed, and inform his customers of the operating and maintenance conditions for the product.

Never begin installing without first checking the compatibility of this product with the associated equipment and accessories. If in doubt when installing this product and/or to obtain additional information, contact a Somfy representative or visit the website www.somfy.com.

1.2. Safety instructions

If used with a motor, you should also consult the instructions provided with the motor.

Do not use or install this product outdoors.

Do not knock or drop the product, expose it to flammable materials or sources of heat or moisture, or splash or immerse it.

Warning

This product contains a cell battery.

Do not swallow the battery: risk of potentially fatal chemical burns in less than 2 hours.

If the battery is inserted into a part of the body or if in any doubt, call a doctor immediately.

Keep batteries (new and used) and the product out of the reach of children. If the battery compartment no longer closes, do not use the product and keep out of the reach of children.

Risk of explosion, leaking flammable liquids or gases from the battery if it is kept at a high temperature (hot oven, fire), crushed, cut or subject to very low air pressure. Non-rechargeable batteries must not be recharged.

2. Situo 1 RTS II and Situo 5 RTS II in detail (Figure A)

- Ⓐ Wall mount recess
- Ⓑ Up / On / Open / Tilt / Increase intensity button
- Ⓒ STOP/my button
- Ⓓ Down / Off / Close / Tilt / Reduce intensity button
- Ⓔ Button activation indicator light
- Ⓕ Button activation and group selection indicator lights
- Ⓖ Group selector switch
- Ⓜ PROG button
- ① Wall mounting.

3. Selection of groups on Situo 5 RTS II (Figure B)

- ① Before performing any operation with the Situo 5 RTS II, check that the correct group has been selected.

- Short press on the group selector Ⓖ: visualisation of the group selected.

- Press several times: change the group selected.

The indicator light ① for each group from 1 to 4 is lit individually then all the indicator lights are lit if group 5 is selected.

4. Installation

4.1. Adding/deleting Situo RTS II

- ① To program the first control: refer to the instructions for the RTS motor or receiver.

To add or delete the Situo RTS II to/from an application: (Figure C)

- 1) On the individual control already associated with the application:

- Press the PROG button (≈ 2 s) until the application moves up and down.

- 2) On the Situo RTS II to be added or removed:







- ① For the Situo 5 RTS II, first select the group Ⓖ.

- Briefly press the PROG button: the application moves up and down and the Situo RTS II is added or deleted.

4.2. Fastening (Figure D)

- ⚠ This product must not be installed at a height greater than 2 m.

The building in which the product is used might reduce the radio range. Never install the control point near or with a metal frame or on metal surfaces, as this can reduce the radio transmission range.



SOMFY ACTIVITÉS SA
50 avenue du Nouveau Monde
F - 74300 Cluses

www.somfy.com

somfy.

EN

- 1) Remove the protective film from the adhesive on the back of the wall mounting.
- 2) Fasten the wall mounting to a flat, clean and dry surface. Press for optimum bonding.
- 3) Place the remote control on the holder.

5. Use

- ① *Before performing any operation with the Situo 5 RTS II, check that the correct group has been selected.*

5. 1. Buttons / (Figure E)

Depending on the type of application to be controlled:

- Brief presses on  or  : up / on / open or down / off / close
- Long presses on  or  : tilt / increase intensity or tilt / reduce intensity.

5. 2. STOP button /my (Figure F)

- Briefly press **my** to stop the application from being activated.
- If the application has been stopped, **briefly** press **my** to activate it until it reaches the favorite position (my).

5. 3. Setting, modifying or deleting the favorite position (my) (Figure G)

- Place the application in the required position then press **my** (≈ 5 s) to set the favorite position (my).
- Place the application in the favorite position (my) and press **my** (≈ 5 s) to delete it.

6. Tips and recommendations

To replace the last control point lost or broken, contact a drive and home automation professional.

7. Replacing the battery (Figure H)

-  Read the section entitled *Safety instructions*.

-  Risk of explosion if the battery is replaced by an incorrect type.

- 1) Step 2) Unscrew the rear cover of the remote control as shown in the diagram.
- 3) Push the used battery out of its housing using a plastic object.
- 4) Insert a CR 2032 3 V battery, with the plus (+) side visible. Make sure the polarity is correct. The power supply terminals must not be short-circuited. Push the battery fully into its housing.
- 5) Step 6) Screw the rear cover back into place.



Please separate storage cells and batteries from other types of waste and recycle them via your local collection facility.



We care about our environment. Do not dispose of the appliance with usual household waste. Give it to an approved collection point for recycling.

8. Technical data

Frequency range and maximum power used:

433.050 MHz - 433.42MHz, 19.9µW average e.r.p.

Operating temperature: 0°C to +48°C

Power supply: 1 type CR2032 battery, 3 V.

This device complies with Industry Canada's licence-exempt RSSs.

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.



FCC warning statement:

-This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

D